



# VOLVO VNL HEADLIGHT ASSEMBLIES INSTALLATION INSTRUCTIONS

**STEP 1:** Raise the hood.

**STEP 2:**  
Remove the tie wrap that is securing the power supply to the light housing.



**STEP 3:**  
Disconnect the power supply line by unclipping the grey portion of the wire harness and squeezing the levers located on both ends of the black and grey plugs.  
*The grey connector acts as a lock mechanism so that the lever will not detach and disconnect while the light is operating.*



**STEP 4:**  
Remove the four bolts from the housing while an assistant holds the light in place



**STEP 5:**  
Once the bolts are all removed, the assistant will be able to replace the headlight assembly with the new VNL LED Projector Headlight Assembly.  
*To install the new headlight, your assistant will need to hold the headlight in place while you pass the wire harness through the housing.*



**STEP 6:**  
Secure the new headlight with the same four bolts that were used to secure the original OEM headlight



**STEP 7:**

HEADLIGHT PLUG

HEADLIGHT RESISTOR PLUG

OEM PLUG



A) Connect Volvo headlight resistor to headlight plug.

B) Connect OEM plug from truck to Headlight resistor

**STEP 8:**  
Once all four bolts are tightened, reconnect the wire harness and push down the grey connector to lock the harness connection.  
*To position the light beam, use a "Torx head socket" to adjust the screw as shown in the image.*



Scan the QR Code to watch the video on how to install.